

The Reef Radiance 23 Point Inspection

- 1. Visually inspect box upon delivery for transit damage
- 2. Open Box remove Light and inspect for transit damage
- 3. Verify all components of Light are inside box
- 4. Manually check all buttons to ensure proper function
- 5. Inspect power cord to make sure it is in operational condition
- 6. Inspect and ensure that power cords fit well into Light body
- 7. Inspect Hanging kit and ensure all wires are securely fastened to holders
- 8. Check mechanical function of White ON/OFF switch to ensure proper function
- 9. Check mechanical function of Blue ON/OFF switch to ensure proper function
- 10. Check mechanical function of White dimmer switch to ensure proper rotation
- 11. Check mechanical function of Blue dimmer switch to ensure proper rotation
- 12. Plug in Light with lights in Off position and ensure fan function is quiet
- 13. Turn on White light switch to ensure that it functions and light comes on
- 14. Turn on Blue light switch to ensure that it functions and light comes on
- 15. Visually inspect White LEDS to ensure that all are on
- 16. Visually inspect Blue LEDS to ensure that all are on
- 17. Turn White dimmer to ensure that it dims properly
- 18. Turn Blue dimmer to ensure that it dims properly
- 19. Turn off White light switch to ensure that it functions and light goes off
- 20. Turn off Blue light switch to ensure that it function and light goes off
- 21. Turn both White and Blue lights on and leave on for 45 minutes to check for any heat issues
- 22. If every function operates as it should, sign check sheet and put check sheet and Light in box
- 23. Re-seal box and mark it ready to ship